

PRODUCT INSTALLATION

FSorb can be cut with a straight edge and a sharp utility knife, insulation knife, table saw or otherwise.

FSorb can be installed directly to a surface with the use of low VOC adhesives, mechanical clips, waferhead tek screws, staples or "buttons."

FSorb can be used as an acoustical core in stretched fabric systems. Mechanically fasten the core to the substrate. Low VOC adhesives may additionally be used. The high density face is installed outwards to the surface of the application. Fabrics can then be stretched over the FSorb core.

FSorb can be furred off the wall or ceiling with the use of a hat channel or similar to create a one inch air space behind it and increase NRC value.

FSorb can be installed into ceiling suspension systems in sizes up to 48" x 96".

FSorb recommends a minimum of 24" attachment points for suspended FSorb panels. Fasteners direct to a surface can also be spaced every 24". Inset fasteners no more than 8" from the panel edges. Do not exceed 24" between fasteners for installations direct to wall or ceiling.

FSorb can be cleaned and maintained as follows: brush off, blow off with compressed air, clean by using a dry cleaning sponge, damp white cloth or similar. Heavy soiling or stains may require a cleaner similar to Resolve Carpet Cleaner or Spot Shot which should be used as directed. Heavily damaged panels should be replaced.

